

GB-Y 97"

ADDENDUM 2

Sept 28, 2008

The rear brace of the main landing gear is just slightly too long. To make it fit properly, the holes need to be drilled out a little larger. **DO NOT BEND THE BRACE TO MAKE IT FIT.** It must be straight in order to be strong.

NOTE: The front and rear holes are not the same size.

Drill through the rear hole (the end of the brace that will mount on the wing) with a 5/32" bit, and drill through the front hole (the end of the brace that will mount to the strut) with a 1/8" bit.

